Aras Innovator 12

Query Builder Guide

Copyright Information

Copyright © 2020 Aras Corporation. All Rights Reserved.

Aras Corporation

100 Brickstone Square

Suite 100

Andover, MA 01810

Phone: 978-806-9400

Fax: 978-794-9826

E-mail: Support@aras.com

Website: https://www.aras.com

Table of Contents

Send Us Your Comments

Aras Corporation welcomes your comments and suggestions on the quality and usefulness of this document. Your input is an important part of the information used for future revisions.

- o Did you find any errors?
- o Is the information clearly presented?
- o Do you need more information? If so, where and what level of detail?
- o Are the examples correct? Do you need more examples?
- o What features did you like most?

If you find any errors or have any other suggestions for improvement, indicate the document title, and the chapter, section, and page number (if available).

You can send comments to us in the following ways:

Email:
Support@aras.com
Subject: Aras Innovator Documentation

Or,

Postal service:
Aras Corporation
100 Brickstone Square
Suite 100
Andover, MA 01810
Attention: Aras Innovator Documentation

Or,

FAX:
978-794-9826
Attn: Aras Innovator Documentation

If you would like a reply, provide your name, email address, address, and telephone number.

If you have usage issues with the software, visit https://www.aras.com/support/

Document Conventions

The following table highlights the document conventions used in the document:

Table 1:   Document Conventions

Convention	Description
Bold	Emphasizes the names of menu items, dialog boxes, dialog box elements, and commands. Example: Click **OK**.
`Code`	Code examples appear in `courier` font. It may represent text you type or data you read.
`Yellow highlight`	Code highlighted in yellow draws attention to the code that is being indicated in the content.
`Yellow highlight with red text`	Red text highlighted in yellow indicates the code parameter that needs to be changed or replaced.
Italics	Reference to other documents.
Note:	Notes contain additional useful information.
Warning	Warnings contain important information. Pay special attention to information highlighted this way.
Successive menu choices	Successive menu choices may appear with a greater than sign (-->) between the items that you will select consecutively. Example: Navigate to **File** --> **Save** --> **OK**.

1 Overview

The Query Builder application enables administrators to build reusable AML queries using a graphical user interface (GUI). The intended use of the Query Builder application is to create queries that can be used in other applications, e.g. Tree Grid Views, Graph Navigation, Access Control, etc. Query Builder can be thought of as the common mechanism that allows users to define and execute queries against Aras Innovator data and data structures to provide useful results for any application needing it.

A Query can be defined to traverse a Relationship structure downward as in a sub-assembly, or upward in a "where-used" manner depending on business requirements. In addition, results can be refined using Where Conditions to produce highly selective output. User-defined Parameters allow input of search parameters to be deferred until runtime.

Specific property values to be returned from the Query can be defined, including xProperties. Output can be sorted according to user-specified order. (For more information about xProperties and xClasses, refer to the Aras Innovator Extended Classification document.)

The Query Builder User Interface includes an **Execute Query** function that displays query results to a subwindow to provide a preview of Query results. This allows end users to test their query, examine the results, and refine their search as needed.

A built-in **Exists()** function allows users to filter items based on the existence or absence of related items. Users can also duplicate Query Definition items and use them to create a Query Definition that is similar to the original.

A common usage of Query Builder results is to be formatted and displayed in a Tree Grid View. The Tree Grid View can generate a Relationship Tab for an ItemType where end users can access the structure display easily. (For more information on the Tree Grid View, refer to the *Aras Innovator 12.0 – Tree Grid View Administrator Guide*.)

This guide walks through building the following sample query:

Figure 1.

2 Developing Query Definitions

Reusable queries are defined by the Query Definition item, found under
Administration\Configuration\Query Definitions in the TOC. The following menu appears:

Figure 2.

When you click **Create New Query Definition**, the following screen appears:

Figure 3.

Each Query Definition starts with an initial **Context Item** before building it out to a more extensive
structure. This specifies the "*root*" of the query, from where query of structures and property values will
begin.

The basic steps for creating a Query Definition are as follows:

1. Define the Context Item.
2. Build the Relationship Structure.
3. Apply Search Conditions.

2.1 Defining a Context Item

The following example creates a Query Definition item for Part ItemType as Context Item. Create a new query definition and specify a unique **Name** and a **Context Item Type**.

Figure 4.

1. Click ![Done]. The Show Editor icon appears in the ribbon.

2. Click the **Show Editor** icon on the left sidebar to go into Query-Editing Mode.

3. Right-click the Context Item and select **Edit Query Element --> Selected Properties**.

Figure 5.

Select the desired properties that the query should return. In this example they are: `id`, `Part Number`, `Name`, `State`, and `managed_by_id`.

Figure 6.

Extended properties enable you to add values such as cost to an object in the database.

4. Right-click on the Context Item again and select **Edit Query Element --> Sort Order**.

5. Choose the properties that should be used for the Order By command and specify whether they should be in ascending or descending order.

Figure 7.

6. Save the Query.

2.2 Building a Relationship Structure

It is possible to define a Relationship from the context item that can go either up or down the data structure. 'Down' refers to a relationship direction starting from the Item representing the *source* side of the relationship and following the related content to the *related* Item. 'Up' by contrast refers to a relationship direction starting from the Item representing the *related* side of the relationship and following the related content to the *source* Item. It is also possible to set up a recursive structure, such as the Part --> Part BOM --> Part, to reuse the same logic for multiple levels. The following procedures show how to expand the query both up and down for a Part Query and introduces recursion.

2.2.1 Building a Downward Relationship Structure

1. Right-click on the Part Context Item and select **Add Related Item --> Using Relationship**.

Figure 8.

2. Select the Relationship to include in the structure. In this case, select **BOM,** check **Include Related** and click **Add**.

Figure 9.

The query now looks like the following. Note that the alias 'Part_1' is assigned to the related Part Query Element in the list.

Figure 10.

3. Right-click on the Part Context Item and select **Add Related Item --> Using Relationship**. In this case, Press **CTRL+click** to select **Documents** and **CAD Documents**. Check **Include Related**.


Figure 11.

4. Right-click on the top Context Item and select **Add Related Item --> Using Item Property**.
   Select an Item Property to add to the query structure. In this case, select **created_by_id**.

Figure 12.

5. Use the following procedure to specify the desired Properties for each new element in the Query
   Definition:

> **Note:** Optionally, you can also set Order By settings as well.

   a. For [created_by_id] User, specify the following properties:
      - Item ID
      - First Name
      - Last Name
      - Login Name

   b. For [Relationship] Part CAD, specify the following property:
      - Sequence

   c. For [Related] CAD, specify the following properties:
      - id
      - Document Number
      - Name
      - State

   d. For [Relationship] Part Document, specify the following property:

- Sequence

e. For [Related] Document, specify the following properties:

- id

- Document Number

- Name

- State

6. Change the Alias on the **CAD Documents** element to "Part CAD":

a. Right-click on **CAD Documents** and select **Change Alias**.

Figure 13.

b. Enter **Part CAD** as the name and click the check mark.

Figure 14.

7. Use the same procedure to change **Documents** Relationship to **Part Document**.

8. Use the same procedure to change **User** Relationship to **Part Created By**.

> **Note:** Each element on a given level must have a unique alias.

9. Save the Query Definition.

2.2.2 Building an Upward Relationship Structure

1. Right-click on the top Part element and select **Add Related Item --> Using Referencing Item**.

Figure 15.

2. Select an appropriate Referencing item from the structure. In this case, select **Simple MCO Part**.

Figure 16.

3. Right-click on the **Simple MCO Part** element and select **Add Related Item --> Using Item Property** to select **source_id**.

Figure 17.

4. Set Selected Properties on the Simple MCO element to:
   - `id`
   - `MCO Number`
   - `Status`
   - `Date Originated`
5. Save the Query Definition.

2.2.3 Adding a Recursive Call Structure

Recursive structures can reuse sections of the already defined queries. The following example shows how to set up a recursive call for the Part --> Part BOM --> Part relationship structure.

1. Right-click on the top-level **Part** element and add the **Part BOM --> Part** structure as shown.

Figure 18.

2. For the BOM element, select the following properties:
   - Sequence
   - Quantity
   - related_id
3. Right-click on the child Part element and select **Reuse Query Element Definition**.

Figure 19.

4. Select the top-level Part element and click **Add**.

Figure 20.

5. Save the Query Definition item.

The child Part item now includes a search for the same elements as the top-level Part, including CADs, Documents, other Parts, etc. It also includes the same Properties and Order By logic as specified above.

2.3 Adding Search Conditions

You can specify Search conditions for every level of the Query Definition Structure. These search conditions can refine the set of data the Query returns. The query logic can include the components shown in the following table:

Comparison Operators	Boolean Operators	Aggregate Functions

`=`
 	
`!=`
 	
`>`
 	
`>=`
 	
`<`
 	
`<=`
 	
`like`
 	
`is null`
	`AND`
	
	`OR`
	
	`NOT`
		`Count()`

Note: Query Builder does not support comparison of string and integer values. For example, you can use logic like `Count(…) = 3`, but you cannot use `Count(…) = "3"`.

Use the following process to add Conditions to the **Query Definition** item:

1. Right-click on the CAD element and select **Edit Query Element --> Condition**.

Figure 21.

2. Enter a search condition such as `[Name] = 'CAD_1'Na`

Figure 22.

Note: Conditions written in Query Builder must be separated by white space. For example, you can use the condition `Cost >= 0` but not `Cost>=0`.

3. Right-click on the Document element and select **Edit Query Element --> Condition**.

4. Enter a search condition such as `[Document Number] like 'A27%'`

Figure 23.

Note: Brackets are placed around multi-word properties in the condition window of Query Builder. You may notice that these brackets automatically disappear for single-word properties.

5. Right-click on the top Part element and select **Edit Query Element --> Condition**.

6. Enter a search condition that enforces the CAD and Document Relationships to exist:

```
(Count([[Relationship]] Part CAD) >= 1) AND (Count([[Relationship]]
Part Document) >= 1)
```


Figure 24.

7. Save the Query Definition.

2.4 Adding/Editing Query Parameters

The following example walks you through the process of defining query parameters. It uses Test Query as an example:

Figure 25.

1. Click the Edit Parameters icon ![icon]. The Query Parameters dialog box appears.

Figure 26.

2. Click the **New** icon ⬚ to add a parameter. Enter the following information:

    Name = doc_state
    Label = Document State
    Default Value = *

Figure 27.

3. Close the dialog box to save the parameter information.

4. Select the **Document** level of the relationship structure and click the associated Filter button to filter using the parameter you just created.

5. Set any other filters and sort orders that you need.

6. Save the Query definition.

The parameters that you add to the Query definition appear in the Map Parameters dialog box in the Tree Grid View:

Figure 28

Once mapped, the parameters become available in the Tree Grid View under the "Modify Parameters" command:

This allows the entry or selection of the configured parameters from the Tree Grid View, setting query parameters in the underlying Query Definition from the Tree Grid User Interface at runtime.

Parameters can also be used for previewing query results when Executing a Query in the Query Builder. See Section 3.0 "Executing Queries" for an example of this.

2.4.1   Structure Resolution Parameter

For structures of Versionable items (like Part/Part BOM Structures) it is useful to examine query results in a Tree Grid View by either the latest versions, or by released versions only, or a combination where if no released components exist then the latest (un-released) version is displayed in the overall structure. The default is to display the structure as it is stored in the database without any optional resolution.

These Resolution Modes are provided to Part BOM Query Definitions (and Tree Grid Views) by a special Parameter which is pre-configured OOTB. Structure Resolution can be applied to any Item Relationship structure of Versionable items that follows the same rules as Part BOM structures – Life Cycle State "Released" (is_released Boolean), incremental Revisions with interim versioned generations, etc.

2.4.1.1   Default Resolution Mode

The **Default** Resolution Mode uses the versions of related child Parts as stored on the BOM Relationships. This is the standard resolution in Aras Innovator.

Part Number	Revision	State
⊟ ⚙ Child A	B	Preliminary
⚙ Child A.1	A	Preliminary
⚙ Child A.2	C	Released
⚙ Child A.3	C	Preliminary
⊟ ⚙ Child B	B	Released
⚙ Child B.1	A	Released
⚙ Child B.2	B	Released
⊟ ⚙ Child C	A	Preliminary
⚙ Child C.1	A	Preliminary
⚙ Child C.2	B	Released

Figure 1.   **Default** resolution mode

2.4.1.2   Latest Resolution Mode

When the **Latest** resolution mode is selected, the structure is resolved starting from the top using the latest versions of child items. When a child item is resolved to its latest version, then its child items are resolved using this resolution mode. This is done recursively.

The **Latest** resolution mode does not consider the released state of the child Parts.

Figure 2.   **Latest** resolution mode

The latest revision **D** of **Child B.2** (Preliminary) is shown where this Part version is in the **Preliminary** state, although the default structure under revision **B** of **Child A** (this structure) refers to revision **B** of **Child B.2** (Released) as stored in the database. In other words, the Latest Resolution Mode dynamically provides a view to in-work changes to released parts that are not yet committed to the released structure.

2.4.1.3   Latest Released Resolution Mode

When the **Latest Released** resolution mode is selected, the structure is resolved starting from the top using the latest versions of child items that are in Released state. When the child item is resolved to its latest Released version, then its child items are resolved using this resolution mode. This is done recursively.

If the related child item has no versions that are in Released state, then a blank row is displayed for that item. There is no further processing on that item.

Figure 3.   **Latest Released** resolution mode

The latest Released versions of child parts are resolved. A blank row is displayed for **Child C** because it has no version that is in the Released state.

2.4.1.4 *Latest Released Or Latest Resolution Mode*

When the **Latest Released or Latest** resolution mode is selected, the structure is resolved starting from the top using the latest versions of child items that are in Released state. If there are no versions that are in Released state, then the latest version is used. When the child item is resolved to a version, then its child items are resolved using this resolution mode. This is done recursively.


Figure 4.   **Latest Released or Latest** resolution mode

The latest Released versions of child parts are resolved. **Child C** does not have any version that is in the Released state. Therefore, its latest Preliminary version is resolved.

2.4.2 Structure Resolution Configuration for Part BOM Structures

In Aras Innovator, the BOM Structure grid (a TGV under the "BOM Structure" tab in the Part form) is pre-configured with a Structure Resolution Parameter, thus it supports *Latest*, *Released*, and *Released or Latest* modes OOTB:

In the event you need to enable Structure Resolution for your Query Definition, you will need to add a Parameter that has a default value of "*Aras.Resolution.EntryPoint;Default*", and then also follow the additional detailed steps for configuring Structure Resolution Parameters described in **Section 7.0**.

For more details and extensive examples of how Resolution Modes are applied in BOM Structures, Effectivity, and 3D Visualization please refer to the following documents:

- *Aras Innovator 12 Dynamic Visualization*
- *Aras Innovator 12.0R2 Product Engineering User Guide*

3 Executing Queries

The query can be executed at any time by right-clicking on the Query structure or by selecting the option from the **Actions** menu.

> **Note:** The results of the query are limited by the User's standard "Get" permissions. In the case of a table row that contains relationship and related_item information you must have "Get" permissions for the related item, otherwise the cells in the row that correspond to the related_item will appear as blank/empty.
>
> Query Builder/Tree Grid View can be configured to use the "keyed_name" associated with the related_item. If there is no "Get" access to the related_item, the keyed_name value will appear as "Restricted."

Executing the query from the top-level element or from the **Actions** menu executes the entire query structure. However, executing the query from one of the child elements returns the results for that substructure only.

Running the **Start Execution** command results in a window that looks similar to the following:


Figure 5.

The window offers an opportunity to add conditions on top of the ones defined by the search, enter parameter values, and set **Max Count**. If Conditions and/or Parameters are unspecified the query is executed without any filtering via conditions or parameters. The Max Count is intended to limit the number of top-level items returned by the search. These settings are recommended during development because the number of elements returned by the query could potentially be very large.

When ready, press the **Execute** command to run the search.

The search for the **Part Query** defined in Section 2 Developing Query Definitions would return a structure similar to the following:

```xml
<AML>
    <Item type="Part">
        <id keyed_name="part_7">82A0B82AAD1C43309075640D21117E90</id>
        <modified_by_id keyed_name="Innovator
Admin">30B991F927274FA3829655F50C99472E</modified_by_id>
        <name>part_7</name>
        <state>Preliminary</state>
        <item_number>part_7</item_number>
        <Relationships>
            <Item type="Part CAD">
                <sort_order>128</sort_order>
                <Relationships>
                    <Item type="CAD">
                        <current_state
keyed_name="Preliminary">A29C9720FF0D4950A140A90BEEA903DA</current_state>
                        <id keyed_name="cad_1">C94B5097E5894EDA8C39C310F735832B</id>
                        <name is_null="1" />
                        <item_number>cad_1</item_number>
                    </Item>
                </Relationships>
            </Item>
            <Item type="Part Documents">
                <sort_order>1</sort_order>
                <Relationships>
                    <Item type="Document">
                        <id keyed_name="Doc_01">FFB47BECC6E64E8BBB8254F0A61E9EEC</id>
                        <name>User Guide</name>
                        <state>Preliminary</state>
                        <item_number>Doc_01</item_number>
                    </Item>
                </Relationships>
            </Item>
            <Item type="Part Created By">
                <id keyed_name="Super User">AD30A6D8D3B642F5A2AFED1A4B02BEFA</id>
                <login_name>root</login_name>
                <first_name>Super</first_name>
                <last_name>User</last_name>
            </Item>
            <Item type="Simple MCO Part (related_id)">
                <Relationships>
                    <Item type="Simple MCO">
                        <created_on>2019-03-21T15:59:26</created_on>
                        <id keyed_name="MCO-100001">A5DCE160DE28465A8ECDFF37CEA6B75C</id>
                        <state>New</state>
                        <item_number>MCO-100001</item_number>
                    </Item>
                </Relationships>
            </Item>
        </Relationships>
    </Item>
</AML>
```

Note:	All child elements of the top-level Part item are returned as `Relationships`, including **created_by_id** and **Simple MCO**.

3.1 Saving Query Results to a Local File

Using the Query Execution Dialog, users can opt to save the results returned to a local file instead of having the results displayed in a pop-up dialog. Saving the results in this manner is for convenience when users would like to review query results using a separate editor.

3.1.1 Save Query Results

To save the results from executing a Query Definition to a local file, select the check box labeled '**Result as File**' prior to executing the query.

Figure 6.   Save Query Results to a File

Once the results are returned to the client, the web browser will provide an interface for the user to select a folder and file name to store the results. The default file name uses the Query Definition name with an '.xml' extension. For example, `MyQueryDefinition.xml`.

4 Sample Query with xProperties

This section describes using Query Builder to create a query using a Part item containing an xProperty.


Figure 7.

The first level of the query contains a Part item that has the **xp-cost** property associated with it. Click the Part Properties button to view this xproperty:


Figure 8.

4.1 Creating a Where Condition

You can create a Where condition using the xpcost property by clicking on the Show Condition button. The Condition box appears:

Figure 9.

1. Enter the following in the Where Condition dialog to return the number of items where the cost is greater than 50:

Figure 10.

2. Click **Save**.

3. Right click Part and select **Start Execution**:


Figure 11.

The Query Result dialog appears:

Figure 12.

As you can see, this query only contains one part item where the cost is greater than 50. You can modify the Where condition so xp-cost > 100. This returns two parts in the result:

Figure 13.

Both parts contain the xProperty xp-cost.

5 Using Max and Min Aggregate Functions in a Query

The following example demonstrates how to use the Max() aggregate function in a Where clause to identify the latest related part using the generation property. The Max() aggregate function returns the maximum value of a specified property. Similarly, the Min() aggregate function returns the minimum value of a specified property. You can use a statement like this in the conditional logic applied to either a Join or Where clause when defining a Query Definition.

1. In the Navigation pane, select **Administration>Configuration>Query Definitions**. The following menu appears:


Figure 14.

2. Click **Create New Query Definition**. A blank query definition window appears:

Figure 15.

3. Enter the Query title in the **Name** field.

4. Click the ellipses in the **Context Item Type** field and select **Part**.

5. Click . The Show Editor icon appears in the ribbon.

Figure 16.

6. Click the **Show Editor** icon. The following window appears displaying the context item.

Figure 17.

7. Right-click on the context item and select **Add Related Item>Using Item Property**.

Figure 18.

The following dialog box appears:

8. Select **config_id** and click **Add**.

Figure 19.

9. Right-click the Where condition icon and select **Change Alias** from the context menu:

Figure 20.

The Change Alias dialog appears.

Figure 21.

10. Change the alias **to Part_LatestReleased_Filter** and click ✓ .

11. Click the **Where** condition icon to create the following join condition for the child part:

Figure 22.

12. Click the **Where** condition icon to create the following where condition for the query:

Figure 23.

13. Click **Save**.

14. Select the parent Part and click the Where condition icon to create the following expression:

Figure 24.

15. Click **Save**. The Show Editor window displays the parent and child parts.

Figure 25.

The query returns the most recent version of released parts associated with a particular config_id.

6 Sample Query with Exists() Function

The `Exists()` Function can be applied in a **WHERE** condition to filter Items based on the *existence* of related items. In essence, it's similar to a **LEFT INNER JOIN** in a SQL statement. To explain the use of such a feature, refer to the basic Query Definition shown here:

Figure 26.

This query will result in returning all Parts in the system. It's equivalent to the SQL statement:

```
SELECT FROM Part
```

The following addition to this Query Definition will add related Parts through the Part BOM Relationship:

Figure 27.

This query will return all Parts, including those Parts that have a Part BOM Relationship along with the related 'child' Part. It's equivalent to the SQL statement:

```
SELECT FROM Part p
  LEFT JOIN Part BOM pb on …
  LEFT JOIN Part child on…
```

The following addition to this Query Definition will add the Condition `Exists([[Relationship]] Part BOM)` on the Context Part Query Item:

Figure 28.

This query will return all Parts that have a Part BOM Relationship along with the related 'child' Part. It's equivalent to the SQL statement:

```
SELECT FROM Part p
```

```
INNER JOIN Part BOM pb on …
 LEFT JOIN Part child on…
```

The effect is to restrict the Part Items returned for the Context Query Item to only those that have related Parts using the Part BOM relationship. Any related Query item can also have conditions applied to it. For example, using the previous example, the Part BOM Query item can have a condition that restricts Items based on a `Quantity > 2`. In this case, the entire Query Definition will only return Parts that have related Part BOM Items that have a Quantity of at least 3.

Figure 29.

The `Exists()` function can be used on any Query item with related content. Note that the Condition Editor will automatically offer valid `Exists()` statements. For Example:

Figure 30.

In this case, beginning to type the '`Exi`' term will isolate the list of valid statements and include all valid ways to use '`Exists()`' for the selected Query item.

7 Structure Resolution Parameters

We mentioned Structure Resolution briefly in the Parameters section above. The Structure Resolution parameter sets query criteria to return a specific configuration of items with respect to Released state and version (generation).

Structure Resolution Modes:

- **Default**: Structure as physically stored in the database. Technically speaking, results will contain Items with ID values in `related_id` Property of Relationships in the structure without interpretation of LifeCycle State or availability of new versions (generations).

- **Latest**: Uses the generation of the Item with the highest value.

- **Latest Released**: Uses the generation of the Item with the highest value which is also Released.

- **Latest Released or Latest**: Uses the generation of the Item with the highest value which is also Released; otherwise the Latest if there are no Released generations.

By default, the structure is only displayed as stored in the database. Without dynamic view parameters users would need to spend more time examining work-in-progress changes to components in a structure. Dynamic structure resolution is important feature for BOM structure, Effectivity, 3D Visualization, and other Aras Innovator features.

In this section we describe in detail how Structure Resolution can be configured for a Query Definition using the Query Builder.

Note:	In Aras Innovator 12.0 SP2 and SP3, there was an error in process Structure Resolution Queries for the Dynamic Viewer in that it would assign the Structure Resolution filter to the root CAD Item. Thus, if a Structure Resolution query was meant to include all Latest Released CAD Items (and the root CAD Item was not Released, the query would return nothing. This has been fixed in 12.0 SP4 and later releases.

7.1 OOTB Example: BOM Structure Resolution

Structure Resolution comes pre-configured for Part BOM Structures OOTB. If you wish to enable Structure Resolution for your own Query Definition its useful to examine the OOTB configuration used in Query Definition PE_BomStructure for reference. Other than naming conventions and base query structure you will follow the same procedure as used for the OOTB implementation when adding Structure Resolution to your Query.

7.1.1 Display Hidden Tabs Under Query Definition

By default, Tabs under the Query Definition itemtype are hidden. Query Definition Itemtype have Relationships to Parameters and Event handlers. We will need them displayed to examine and configure Structure Resolution.

As administrator, edit the Itemtype qry_QueryDefinition and change the Default Structure View to "Tabs On" as shown on right. If the tabs do not appear for Query Definition form, then you may need to exit the Query Definition and re-open to refresh the form.

Name	History Template
qry_QueryDefinition	
Singular Label	**Plural Label**
Query Definition	Query Definitions
Show Parameters Tab	**Default Structure View**
When Populated	Tabs On

7.1.2 Check Parameter Tab

Once displayed, you will have access to relationships under the Query Definition as Tabs. Recall from **Section 2.4** that Parameters are essentially runtime variables configured in the Query Builder to provide runtime variables (i.e. search criteria) to the underlying query.

Under qry_QueryParameter tab, you will see all Query Parameters defined for this query. For Bom Structure OOTB, Parameter "StructureResolutionMode" is pre-configured with the default value "Aras.Resolution.EntryPoint.Default" as shown below.

If adding Structure Resolution to your custom query, you will need to add a Parameter and assign the Default Value "Aras.Resolution.EntryPoint.Default" as shown below. This procedure is detailed in section 7.2.

Query Definition

Name	Context Item Type
PE_BomStructure	Part BOM

Description

qry_QueryItem   qry_QueryReference   **qry_QueryParameter**   qry_QueryDefinitionEvent

⬡ qry_QueryParameter ∨ ☆

[Hidden ∨]

Name	Label	Default Value [...]
StructureResolutionMode		Aras.Resolution.EntryPoint;Default

7.1.3 Query Definition Events Tab

Beside the Parameters tab in the Query Definition form is the *qry_QueryDefinitionEvent* tab. In the OOTB Bom Structure Query Definition you will see an Event Handler that tells the query to run a method named "*qry_ResolveStructureEntryPoint*" before query execution (event "OnBeforeExecute"). This method is provided OOTB, providing the logic to resolve structures according to the selected Parameter value (Latest, Latest Released, Latest Released or Latest).

When adding Structure Resolution to your custom query, you will need to add this event handler and define the method and event name exactly as set in the BOM Structure query definition.

In Summary, the Parameter and Event Handler tells the Query Definition to (a) allow runtime entry of Latest/Released criteria and (b) specifies method logic to execute to enforce Structure Resolution behavior on execution of a query.

7.1.4 Reference to Parameter in Join Condition in Query

Once the Parameter is added to the Query Definition and the Event Handler set, the Parameter can be dereferenced in the Join Condition of the query item to be resolved using the $Name syntax below. In the BOM Structure example, the resolved query item is the Part node, therefore the Join condition is edited to use '$StructureResolutionMode.parent.related_id' = Part.id.

Sections 7.1.1 – 7.1.4 describe the same configuration settings you would use to enable Structure Resolution on your custom query, or another Query Definition applied to a structure of related versionable items such as CAD Structures. The next section covers this procedure in detail.

7.2 Enabling Structure Resolution in a Query Definition

Structure Resolution can be applied to any Item Relationship structure of Versionable items that follows the same rules as Part BOM structures – Life Cycle State "Released" (is_released Boolean), incremental Revisions with interim versioned generations, etc.

- CAD Structure is an example of such a structure, and Structure Resolution can be applied to Query Definitions against this data model in the same manner as Part BOM structures. We use CAD Structure as an example of this procedure which is documented in greater detail in *Aras Innovator 12 Dynamic Visualization*

Per the Part BOM Query Definition we examined in Section 7.1, Structure Resolution requires a Parameter with the Resolution Entrypoint, an Event Handler must be added to the Query, and the Parameter must be referenced in the Join Condition for the resolved itemtype.

Adding the Structure Resolution configuration to a CAD Structure Query will involve all of these steps as well.

Step 1: Create Structure Resolution Mode Parameter

Applying a specific Structure Resolution Mode ('Default', 'Latest', etc.) is done using a Query Parameter. Using the Query Parameters Dialog, add a Parameter to be used for Structure Resolution Mode. For example 'StructureResolutionMode' and assign the default value 'Aras.Resolution.EntryPoint;Default'

Note: Be sure to check the syntax of the Default Value for the Parameter. It is used to select a specific List Item as set in the Tree Grid View Definition and described below in Step 4.

Step 2: Incorporate the Query Parameter in Join Condition

The added Query Parameter must be incorporated into the Query Definition in order for it to be used/exposed to the end-user. Add it as part of the Join Condition of the Child CAD Query Item as shown in **Error! Reference source not found.**. Replace the default Join Condition – e.g. '[Part BOM].related_id = Part.id' with the following – ''$StructureResolutionMode;parent.related_id' = Part.id'

Part BOM and Part are used for this example, but it could just as well be '[myLinkage].related_id = myNode.id' being replaced by '`$StructureResolutionMode;parent.related_id' = myNode.id`'.

Note: Be sure to check the syntax of the Join Condition. It must be as specified above (without the outer quotes). This assumes the value `StructureResolutionMode` was used for the Query Parameter Name. If you named the Parameter differently, e.g. `myParam`, then you would naturally need to dereference it as `$myParam` in the expression.

Note: The Structure Resolution Mode Query Parameter can only be inserted once in a Query Definition. It cannot be used/applied to more than one Query Item.

Step 3: Add Structure Resolution Method to Query Event Handler

Show the Relationship Tabs for the Query Definition in the Form View if they are not shown. Tabs On/Off is set in the Query Definition itemtype (qry_QueryDefinition).

Select the `qry_QueryDefinitionEvent` Relationship Tab. A Method needs to be added to the `OnBeforeExecute` event. To do this, select the **Select Items Icon** to create a Relationship and select the `qry_ResolveStructureEntryPoint` Method and assign it to the `OnBeforeExecute` event as shown in Figure 31.


Figure 31.   Assigning Structure Resolution OnBeforeExecute Method

Step 4: Map the Query Parameter in the Tree Grid View Definition

In order for the Query Parameter to be used in a **Tree Grid View**, it must be enabled (made visible) in the Tree Grid View Definition.

Open the Map Parameters Dialog in the Tree Grid View Definition within the Editor View. All Parameters defined in the Query Definition used by the Tree Grid View will be listed.

Select the **Visible** check box for the `StructureResolutionMode` row. The **Data Type** is a `List` and the **Data Source** is the List `qry_StructureResolution`.


Figure 32.   Mapping Tree Grid View Definition Query Parameters

With this Configuration in place, users will be able to select specific Resolution Modes by opening the Query Parameters Dialog in the Tree Grid View used within the 3D Viewer.


Figure 33.   Tree Grid View Parameter Dialog

7.2.1.1   Applying a Where Condition Against Resolved Items

In Aras Innovator 12.0 SP4 and later releases it is possible to add a Where Condition to a Query Item that is used for Structure Resolution (e.g., CAD in this example). Doing so allows the Administrator to apply an additional condition (filter) when resolving the Structure of Items with fixed Relationships (such as CAD / CAD Structure). For example, assuming the CAD Structure in the following diagram:


Figure 34.   Structure Resolution Logic with Condition

If the Administrator would like to use Structure Resolution of 'Latest' and apply an additional condition to only include CAD Items that were *In Review* (that is, with a CAD.State = 'In Review') then Where and Join conditions like the following could be added to the Query Item:

Figure 35.   Where/Join Condition Example for Structure Resolution

Note the addition of the left-side of the Join Condition:

`'$StructureResolutionMode;parent.related_id;`**`ApplyChildWhereMode=ResolutionTar getResolved`**`' = CAD.id]`

Executing this Query Definition, with Structure Resolution of '*Latest Released*' with return:


Figure 36.   Structure Resolution Logic with Condition Result

In this example, only the CAD Item – CS3, version 5 is returned because of the added Where Condition of `CAD.State = 'In Review'` applied to the resolved results of the Structure Resolution Join Condition using the selected Mode parameter.

For more details and extensive examples of how Resolution Modes are applied in BOM Structures, Effectivity, and 3D Visualization please refer to the following documents:

- *Aras Innovator 12 Dynamic Visualization*
- *Aras Innovator 12.0R2 Product Engineering User Guide*